

# Product data sheet

## Brake bleeding device



### Description

#### brake bleeding device

Easy to bleed your brake without any help. With the well thought-out system, simply insert the hose with the special nipple onto the open bleed nipple after connecting the compressor and pressure in the system, press the brake bleeder. This results in a negative pressure of about 60% so that the old brake fluid is transferred into the container. Using the brake fluid reservoir, fill fresh brake fluid until fresh brake fluid comes out from the bleed nipples. Then close the bleed nipple so that no fluid can leak any further. Always start with the longest path from the brake fluid reservoir to the bleed nipple.

**The following accessories are required for the device: 6.622015/3 quick-action coupling with outer thread or 6.622072/4 plug nipple with outer thread!, volume: 1l**

|                  |                |
|------------------|----------------|
| Article number:  | 05758909       |
| Original number: | 015-6331       |
| EAN:             | 99999999       |
| EVP:             | <b>44.68 €</b> |

| Technical data       |                |
|----------------------|----------------|
| Design               | brake          |
| Features             | set            |
| Range of application | brake bleeding |
| Main colour          | transparent    |
| Secondary colour     | black          |
| Filling quantity     | 1000 ml        |
| Material 1           | plastic        |
| Weight               | 0.412 kg       |